

Connector/Harness diagram

GND	GND	17	□ □	01	GND	GND
Pulsed VCC	VSS/Speedometer	18	□ □	02	RPM/Tachometer	Pulsed VCC
Analog	Fuel level	19	□ □	03	12v ignition switch	-
-	-	20	□ □	04	Left turn	Digital VCC
-	-	21	□ □	05	Parking lights	Digital VCC
Analog	Engine temperature	22	□ □	06	Radiator fan	Digital VCC
-	Live 12v	23	□ □	07	Rear defroster	Digital VCC
Digital GND	RESET	24	□ □	08	-	-
Digital GND	Open door	25	□ □	09	-	-
Digital GND	Parking Brake	26	□ □	10	ECU/Check engine	Digital VCC
Digital GND	4x4	27	□ □	11	Fog lights	Digital VCC
Digital GND	Alternator	28	□ □	12	Aux lights	Digital VCC
Digital GND	Oil pressure switch	29	□ □	13	High beam lights	Digital VCC
	5v output	30	□ □	14	Right turn	Digital VCC
CAN	CAN-LOW	31	□ □	15	CAN-HIGH	CAN
GND	GND	32	□ □	16	GND	GND

